



Steel Platform Off-Loading Instructions

The platform will arrive loaded on the truck in one of two ways:

1. In the operating position (upright)
2. On its side



Off-Loading Instructions for Upright Platform

- Locate the center line of the platform. Using an 8,000 lb. capacity (recommended) forklift and 8 ft. fork extensions, spread the forks as wide as possible.
- Position the forklift so that the forks are centered under the platform.
- Pick the platform up off the truck making sure the load is balanced.
- After the platform is balanced and has been lifted off the truck, pull the truck forward until the platform clears the trailer.
- Lower the platform and position it in the desired location.

Off-Loading Instructions for Side-Loaded Platform

- Position a lifting strap through the lift hook that is welded to the side of the platform (on top when platform is on its side).
- Position the forklift so that the strap wraps around and is secured to the forks of the forklift.
- Pick the platform up off the truck making sure that the load is safely secured to the forks.
- Once the platform is off the truck, pull the truck forward until the platform clears the trailer.
- Begin to lower the platform. Use a second forklift (lifting from the bottom of the platform) to maneuver the platform into an upright position.
- Once the platform is on the ground, position the forklift so that the forks are centered under the platform.
- Pick the platform up and place in the desired location.