


INSTALLATION INSTRUCTIONS

MODEL: 20090 OAK SOLO

THANK YOU FOR YOUR PURCHASE. We take a **SATISFACTION GUARANTEED** approach to our products and our business, if you are not satisfied in any way, or if we can provide you with assistance or information, PLEASE call us TOLL FREE at 800-346-7332 or e-mail us at contactus@mygearup.com.



Bill of Material		
A.	Oak Wall Plate	1 ea
B.	Oak Arms	2 ea
C.	Short Wood Screws	4 ea
D.	Long Wood Screws	2 ea
E.	Wood Shaker Pegs	3 ea
F.	Wood Plugs	2 ea
G.	Velcro Strap	1 ea

The GEAR-UP™ SOLO OAKRAK is designed to hold a single 2 wheel, non-motorized bicycle when mounted to wall. The total weight of the bicycle cannot exceed 50 pounds.

ASSEMBLY & INSTALLATION INSTRUCTIONS

1. Attach arms to back plate as shown in Figure A above. Note the arm cut out or cup must face upward. Attach using the 4 short Wood Screws (C).
2. Select wall location where rack is to be mounted. Use 2 upper mounting holes for attaching to wall. Locate wall studs. Note: Mounting holes are on 16-inch centers. If the wall studs are less than or greater than 16 inch centers, you will need to attach a wall plate to the wall that spans at least 2 studs and attach your rack to the wall plate.

NOTE:

Before drilling into any wall or stud, be sure no Electrical, Water, Gas or other obstructions are present.

3. Using back plate of Bike Rack, determine position where rack is to be attached to wall. Attach completed rack assembly to wall using 2 long Wood Screws (D) inserted into 2 upper corners holes. Be sure to pre-drill mounting holes into wall stud before attaching.
4. Once firmly in place, insert 3 pegs into bottom corner holes and center hole of the back plate. Press fit into place. You may also use a small amount of wood glue to permanently attach.
5. Insert small wood plugs to hide mounting holes in the top left and right corners of the back plate. Press fit into place.

USE

1. Gently lift bicycle onto arms. Be sure Bicycle is centered and balanced.
2. Use Velcro Strip to hold front wheel in place, i.e., keep from turning. Insert strip through Wheel and around frame.
3. In removing bicycle, gently lift up and away from rack. **DO NOT EXERT** pressure onto holder arms.
4. **DO NOT EXCEED** weight restrictions of 50 pounds.
5. Hang helmet, shoes, etc. from wood pegs.
6. **User assumes complete responsibility for the proper installation and use of this product.**

WARNING

DO NOT STEP, CLIMB, OR HANG ON THE STORAGE RACK

DO NOT ALLOW SMALL CHILDREN OR PETS TO PLAY IN, ON, OR AROUND THE STORAGE RACK. IMPROPER INSTALLATION AND/OR USE OF THE STORAGE RACK COULD CAUSE SERIOUS INJURY AND/OR DEATH.

User assumes total responsibility for the proper installation and use of this product. GearUp Inc. will not be held liable for damages or injuries resulting from the installation and/or use of this product. If the installer or user is unsure of the requirements described herein, it is his/her responsibility to seek adequate professional assistance or contact our customer care center at 800-346-7332. **REMEMBER** – stored items can fall resulting in injuries and/or property damage when not properly installed or used.

THANK YOU again for your purchase. We have worked hard to make sure the product you purchased is of top quality and that all parts and necessary instructions have been included. If we have overlooked anything, or if we can be of assistance, help walk you through installation, or offer tips on how to use our product, **PLEASE** give us a call on our **Toll Free Customer Hotline 800-346-7332. YOUR SATISFACTION IS OUR TOP PRIORITY.**

Visit us at our web site www.mygearup.com for other storage solutions and special offerings.